

**Belkin OmniView® Secure KVM Switch User Manual F1DN102U F1DN104U F1DN108U Common Criteria supplement**

This section supplements the Belkin Quick Installation Guide in accordance with ADO\_IGS.1 Common Criteria Assurance Measure requirements.

This User Guidance and Common Criteria EAL 4 validation apply to the TOE Common Criteria Evaluated version of OmniView™ Secure KVM Models listed below:

F1DN102U Version v.321211

F1DN104U Version v.321211

F1DN108U Version v.321211

Before you begin: The Users of the Belkin OmniView™ Secure KVM must review all associated documentation and guidance, prior to proceeding with installation and use of the KVM switch.

**1.1 Receipt and preparation of TOE and Environment prior to installation**Receipt

- Assure that tamper seals are intact on the KVM switch.

Environment preparation

- The Belkin OmniView KVM secure must be located in a physically secure location providing physical protection and limited (authorized user) access controls.

**1.2 Verification of Common Criteria components**

The following are authorized devices for the Common Criteria Evaluated configuration. Assure that installation processes resulting in the following hardware/firmware configuration:

TOE	Belkin Secure KVM Switch 2 Port PN # F1DN102U v.321211 (or) Belkin Secure KVM Switch 4 Port PN # F1DN104U v.321211 (or) Belkin Secure KVM Switch 8 Port PN # F1DN108U v.321211 (and) Firmware Version 3.16
Environment	USB Mouse (Peripheral Group Member)
Environment	USB Keyboard (Peripheral Group Member)
Environment	Monitor – VGA connector (Peripheral Group Member)
Environment	Host Computers Qty 2, 4 or 8 based on KVM used (IT Environment Computer resources)

### **1.3 Usage Assumptions**

The Common Criteria Evaluated Configuration requires the following assumptions in usage of the OmniView Secure KVM device. These assumptions should be assured either through facility or procedural provisions.

- An AUTHORIZED USER possesses the necessary privileges to access the information transferred by the TOE.
- USERS are AUTHORIZED USERS.
- The TOE meets the appropriate national requirements (in the country where used) for conducted/radiated electromagnetic emissions. [In the United States, Part 15 of the FCC Rules for Class B digital devices.]
- Only the selected COMPUTER'S video channel will be visible on the shared MONITOR.
- The TOE is installed and managed in accordance with the manufacturer's directions.
- The AUTHORIZED USER is non-hostile and follows all usage guidance.
- The TOE is physically secure.
- Vulnerabilities associated with attached DEVICES (SHARED PERIPHERALS or SWITCHED COMPUTERS), or their CONNECTION to the TOE, are a concern of the application scenario and not of the TOE.

## **2. Common Criteria Administrative Guidance - OmniView® Secure KVM Switch User Manual F1DN102U F1DN104U F1DN108U**

The follow section lists the supplemental information relating to a Common Criteria deployment for the OmniView® Secure KVM Switch User Manual in accordance with AGD\_USR.1 & AGD\_ADM.1 Common Criteria Assurance Measure requirements.

### **Usage Assumptions**

Note that the usage assumptions listed in Section 1.3 must be maintained to assure all TOE security objectives are maintained during usage.

### **Applicability of OmniView® Secure KVM Switch User Manual to Common Criteria**

The OmniView Secure KVM Switch User Manual applies in its entirety to the Common Criteria Evaluated Configuration.